

# QUARTERBACK



## OWNERS AND SERVICE MANUAL

The Jumping Bean Company / Bell-Fruit Games Ltd. / Mazooma Games Ltd.

Distributed By:

**INNOVATIVE CONCEPTS IN ENTERTAINMENT INC.**

10123 MAIN STREET, CLARENCE, NY 14031

SERVICE: 1-716-759-0360 FAX: 1-716-759-0884

E-MAIL: [service@icegame.com](mailto:service@icegame.com)

WEBSITE: [icegame.com](http://icegame.com)

# **Table of Contents**

1. **Copyright**
2. **Warranty**
3. **Safety Instructions.**
  - 3.1 Product Safety
  - 3.2 Electrical Safety General
  - 3.3 Chemical Safety
  - 3.4 Fire Safety
  - 3.5 Disposal of Hazardous Components
4. **Installation Instructions & Daily Checks**
  - 4.1 General
  - 4.2 Physical check
  - 4.3 Internal Electrical connections
  - 4.4 Electrical Supply
  - 4.5 DIL Switch Settings at Power Up
  - 4.6 Dimensions
  - 4.7 Fitting the Top Display.
  - 4.8 Abbreviations
  - 4.9 Daily Checks
5. **Game description**
  - 5.1 Description

## Table of Contents

### **6. Operator Adjustments.**

- 6.1 Pendulum Tilt Assembly
- 6.2 Adjustment of Lose Hole size
- 6.3 Adjustment of Tilt Time
- 6.4 Playfield Riser

### **7. Fault finding guide.**

- 7.1 Machine does not work
- 7.2 The tilt does not work
- 7.3 The tilt will not stop
- 7.4 No ticket pay out
- 7.5 The halogen lamps do not work

### **8. Regulated Parameter Settings**

- 8.1 Set stake
- 8.2 Set ticket/pntr
- 8.3 Set mercy ticket
- 8.4 Set prize left
- 8.5 Set prize right
- 8.6 Disply vib
- 8.7 Set vib level
- 8.8 Auto load bed

## **Table of Contents**

### **9. Test Sequences & Procedures**

TEST 1.1 COIN IN

TEST 1.3 NOTES IN

TEST 3.2 LAMPS

TEST 6.1 METERS

TEST 7.1 COMMS

TEST 8.1 AUDIO

TEST 8.2 VOLUME

TEST 10.1 LAMPS

TEST 10.3 CLEAR NVR

TEST 10.4 COIN DATA

### **10. DIL Switch Settings and Functions**

### **11. Machine BOM (including Illustrations)**

# COPYRIGHT

The Jumping Bean Company / Bell-Fruit Games Ltd. / Mazooma Games Ltd. possess exclusive copyright in the SOFTWARE & HARDWARE contained within this machine. Purchasers have no authority to reproduce any part of The Jumping Bean Company / Mazooma Games Ltd. software, including copying of EPROMS, unless permission is granted in writing.

The Jumping Bean Company / Bell-Fruit Games Ltd. / Mazooma Games Ltd. also retains various intellectual property rights in the form of LETTERS PATENT, REGISTERED DESIGNS and TRADE MARKS (both in force and pending) applicable to this machine. The purchaser's right to use these is restricted to operation of the machine in its original form, or in modified form ONLY IF such modifications have been carried out under

The Jumping Bean Company / Bell-Fruit Games Ltd. / Mazooma Games Ltd. express written licence to do so. Particular note should be taken of any patent numbers identified within the artwork design or game manual of this machine.

Copyright also exists in the ARTWORK DESIGNS for this machine. No part of this artwork may be reproduced in any way without written authority.

The THREE BELLS DEVICE, JUMPING BEAN DEVICE & SCORPION 4 TM are REGISTERED TRADEMARKS of Bell-Fruit Games Ltd.

PERSONS WISHING TO MAKE USE OF ANY OF THE INTELLECTUAL PROPERTY ABOVE SHOULD CONTACT MAZOOMA GAMES LTD IN THE FIRST INSTANCE

# WARRANTY

Seller warrants that its microprocessor unit and parts thereon, are and shall remain free from defects in material and workmanship under normal use and service for a period of six months from date of purchase.

Seller warrants that other products or parts thereof shall remain free from defects in material and workmanship under normal use and service for a period of 90 (ninety) days from date of purchase.

If the products described in this manual fail to conform to this warranty, seller's sole liability shall be at it's option to repair, replace or credit buyer's account for such products which are returned to seller during said warranty period, provided:

- a) Buyer promptly notifies seller in writing upon discovery that the said products are defective.
- b) Such products are returned prepaid to seller's plant.
- c) Seller's examination of said products discloses to seller's satisfaction that such alleged defects existed and were not caused by accident, neglect, alteration, improper repair, installation or improper testing.
- d) Only seller's recommended or approved electronic components are used as service replacements.

In no event shall seller be liable for loss of profits, loss of use, incidental or consequential damages.

Except for any express Warranty set forth in a written Contract between Seller and Buyer, which Contract is expressed, to supersede the terms of this warranty, all implied warranties and conditions as to quality or fitness for any particular purpose are hereby expressly excluded.

No employee of the Seller has any authority to waive or amend the terms of this warranty that shall be deemed accepted by the Buyer on acceptance of the products referred to above.

**ALL WARRANTY CLAIMS FOR THIS MACHINE WILL BE DEALT WITH BY THE BELL-FRUIT GAMES AFTERSALES DEPARTMENT.**

Tel: 0115 9706707

E-MAIL: [technical@bellfruitgames.co.uk](mailto:technical@bellfruitgames.co.uk)

## **SAFETY INSTRUCTIONS**

### 3.1 Product Safety

An equally wide range of manufacturers supplies the wide range of components used in the machine. It is therefore impracticable for this document to provide comprehensive safety data for each product used. Manufacturers data sheets can be supplied upon request.

All the items contained within the machine are used within their specification limits and in accordance with sound engineering practice.

### 3.2 Electrical Safety General

All machines are tested for electrical safety prior to being despatched. The tests are for Earth Bond and Insulation. It is recommended that these tests are repeated annually or whenever safety critical parts and connections are replaced.

Disconnect the mains power supply before attempting to dismantle or repair any part of the machine.

Always observe high voltage and hazard warning labels.

Be aware of capacitors fitted to the machine PSU. Use only the specified fuses stated in the machine and in this manual.

Always refit safety covers and safety earth wires connected to metal parts.

Earth/Insulation specifications for BFG machines are: -

Insulation > 2 Megohms @ 500V dc.

Earth Bond < 0.25 ohms @ 25 amps.

## **SAFETY INSTRUCTIONS**

### 3.3 Chemical Safety

Attention is drawn to the possible effect of accidental damage to components where they contain chemicals that may be hazardous. Components that fall into this category are: -

**Electrolytic Capacitors**

**Nickel Cadmium Batteries**

**Semi-Conductors containing Beryllium Oxide and  
Gallium Arsenide**

**Opto-Electronic devices using Gallium Phosphide**

As the chemicals are corrosive or flammable, particular care must be exercised in case of spillage. Any part of the body that accidentally comes into contact with these chemicals must be thoroughly washed in cold running water, particularly if the eyes are affected. Medical advice should be sought.

### 3.4 Fire Safety

Outer casings of the majority of the components used are made of heat resistant material. Excessive electrical overload conditions may generate sufficient heat to ignite chemical substances within the components themselves or adjacent components, harnesses etc.

**NOTE: It is imperative that only identical value components are used as replacements for the original equipment supplied and that correct polarity of assembly is observed when applicable.**

## **SAFETY INSTRUCTIONS**

### 3.4 Fire Safety (continued)

Materials that fall into the Fire Hazard category are: -

**Chipboard and MDF** - releases Formaldehyde vapours when ignited, causes discomfort to the eyes and mucous membranes.

**Plastic Laminates** - plastic and rubber mouldings, wire insulation etc., release noxious fumes, which if inhaled may cause irritation depending on the sensitivity of the individual.

**Glass** - extreme heat will cause the glass to crack thereby causing injury.

**Electrolytic Capacitors** and **Batteries** - may explode if subjected to fire.

**Foamex** – flammable.

### 3.5 Disposal of Hazardous Components

As a general rule, electronic components should not be incinerated due to the possible danger of noxious fumes being released, or components exploding due to a build up of internal pressures created by expanding gases.

# INSTALLATION INSTRUCTIONS & DAILY CHECKS

## 4.1 General

It is the policy to ensure that all products are designed, manufactured, tested and released to conform to statutory safety requirements. In support of this policy the information contained within this manual is intended as a guide to the safe installation, reliable working and efficient operation of the machine supplied.

Therefore prior to installation or when servicing, reference to the service manual and all **WARNING LABELS** provided is strongly recommended. Failure to observe any information may result in a safety hazard.

**CAUTION:** Under no circumstances should any major form of installation, repair, adjustment or maintenance be attempted by any other than qualified personnel.

## 4.2 Physical Check

Ensure that the machine is positioned on a level stable surface and remove all of the transit packaging. Open all doors and check that all parts are secured, electrical connectors are correctly mated and that no components or assemblies have been damaged in transit.

## 4.3 Internal Electrical Connectors

The introduction of insulation displacement connectors (IDC) and the use of lighter cables emphasise the need for care when removing and replacing connectors.

When removing connections, pull on the connector and not the wires; when replacing connections ensure that (i) the harness housing is being connected to the correct wafer (ii) the housing is the correctly oriented (Observe positions of polarising pins).

## INSTALLATION INSTRUCTIONS & DAILY CHECKS

### 4.4 Electrical Supply                      **WARNING: This Apparatus must be EARTHED.**

Connect the machine to the mains supply (110/120Vac) using an approved plug. The mains lead is factory fitted to the machine.

**IMPORTANT:** The wires in the mains lead are coloured in accordance with the following code.

GREEN AND YELLOW	:	EARTH
BLUE	:	NEUTRAL
BROWN	:	LIVE

As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows.

1.    EARTH:        The wire coloured GREEN and YELLOW must be connected to the terminal marked 'E' or by the safety earth symbol or coloured GREEN, or GREEN and YELLOW.
2.    NEUTRAL:     The wire coloured BLUE must be connected to the terminal marked 'N' or coloured BLACK.
3.    LIVE:         The wire coloured BROWN must be connected to the terminal marked 'L' or coloured RED.

### 4.5 DIL Switch Settings at Power Up

On machine power up, please ensure that all DIL switches are in the OFF position bar DIL switch 16 which should be on.

# INSTALLATION INSTRUCTIONS & DAILY CHECKS

## 4.6 Dimensions

Height	1840 mm
Width	710 mm
Depth	709 mm
Weight	135 Kg

## 4.7 Fitting Top Display

If the Top Display is separate from the machine, remove any packing material and position the top display on cabinet top. Make sure electrical connections are in the correct position.

The top sign electrical connection is in play section two.

Use M6 nuts and washers supplied to secure top display to cabinet top.

## 4.8 Abbreviations:

- **Coin Entry** - slot in the coin entry panel where player may insert a coin to play.
- **Coin chute** - metal chute that guides a token from the escalator hopper to the centre pin perspex.
- **Centre pin perspex** - large perspex panel fitted with scatter pins that guide the coin down onto the pusher pad.
- **Pusher pad** - the moving pad assembly located at the rear of the playfield.
- **Playfield** - flat bed holding the coins to be pushed into the win chute.
- **Win chute** - large metal form located under front edge of playfield to guide falling tokens to the escalator hopper.

## INSTALLATION INSTRUCTIONS & DAILY CHECKS

### 4.9 Daily Checks:

- Check the machine is clean inside and outside
- Check all the lamps are working.
- Check pusher pads are moving.
- Check coin chutes are clear of any jammed coins or foreign matter.

## Game Description

### 5.1 Description

The standard pusher has a playfield with a reciprocating pusher that continuously moves back and forwards and a swinging arm chute to direct the coins. All coins accepted increments the game credits on the alphanumeric display. No coins inserted go to the playfield.

All coins that are fed on the playfield are dispensed from the escalator hopper and all coins pushed over the playfield are counted the returned to the escalator hopper in a continuous loop.

The player has a "Fire" button to dispense the required number of coins to the playfield and a "Skill stop" button which enables the player to place his coin on the playfield in the desired position with the swinging arm.

Any coins pushed forward over the front of the playfield are counted then banked as wins on the alphanumeric display. Coins falling down the sides are "lose holes" and are returned to the escalator hopper without being counted.

If the machine is tilted during play, any coins counted during this period are not banked as wins. When the machine stabilises, these coins are returned to the playfield.

Banked wins may only be collected when the machine is out of credit.

All coins are paid with separate hoppers in the normal way.

A serial meter monitors accountancy.

## Operator adjustments

### 6.1 Pendulum tilt assembly.

There is one pendulum tilt assembly located inside the cabinet, near the top to the left of the back door.

(See figure 2).




Figure 2 - pendulum tilt.

This swinging weight type assembly is designed to detect moving or tipping of the machine and needs no adjustment as long as the weight is central to the circular contact and is free to move.

### 6.2 Adjustment of “lose” hole size.


The “lose” holes are located one each side of the front edge of the play-field, are factory set. It is not recommended changing this setting

## Operator adjustments

### 6.3 Adjustment of Tilt time.

The tilt time period can be adjusted as follows:

- Remove the bottom service door from section one.
- Locate the small PCB mounted near to the isolating switch.
- With a small screwdriver, turn the small control anti-clockwise to increase the tilt time.
- The factory setting is ten seconds.



### 6.4 Playfield Riser.

Located at the play-field front edge.

The angle of the hinged chromium plated riser is factory set according to the coin of play.

Loosening the lock nut and turning the screw at the center of the riser can adjust this angle.

Turning the screw clockwise causes a steeper angle. An increased angle causes an increase in coin build-up and vice versa.

## Fault - finding guide.

### 7.1 The machine does not work

#### Check

- Mains wall outlet is switched “on”.
- “On/off” switch on the power supply.
- Damage to mains inlet cable.
- Fuse 1 (T10A) located on the power in line.

### 7.2 The tilt does not work.

When the machine is tilted (pendulum tilt in top) “TILT” is displayed on the alphanumeric for 30 seconds.

#### Check

- The tilt contacts are not dirty or so far apart they do not touch when the machine is banged.
- The orange/green and black wires are connected.

### 7.3 The tilt will not stop.

#### Check

- The tilt contacts are not bent together.
- The pendulum tilt is operating

### 7.4 No ticket pays out

#### Check

- There are tickets at ticket dispenser.
- There are no ticket jams.
- Electrical connections to ticket dispenser.
- Check the coin count hopper is functioning correctly

## **Fault - finding guide.**

### 7.5 The halogen lamps do not work.

The 12v 50w halogen lamps are connected to the torroidal transformer on the centre lighting shelf behind the power supply unit. The lamps are wired in pairs and each pair is protected by an in line fuse.

#### **Check;**

- The 5-ampere inline fuses and wiring connections

## Regulated Parameter Settings

A test facility is provided to set certain machines parameters. The following tests are only applicable to machines with an alphanumeric fitted.

During test, the front door must remain open, the machine must not be in credit or the counters will not operate.

To enter the test routines,

- open the front door of the machine
- ensure DIL switch 16 is on
- ensure all other DIL switches are OFF
- press the green test switch once.

The following rules apply to all tests:

1. To scroll down through the parameter settings press the left-hand button.
2. To scroll up through the parameter settings press the centre button.
3. To enter any of the parameter settings press the right hand button.
4. To set any of the parameter settings press the right hand button.
5. To exit any of the parameter settings press the right hand button.

Each test is identified as follows:

- i) SET STAKE
- ii) SET TICKET/PNTR
- iii) SET MERCY TICKET
- iv) SET PRIZE LEFT
- v) SET PRIZE RIGHT
- vi) DISPLY VIB
- vii) SET VIB LEVEL
- viii) AUTO LOAD BED

## **Regulated Parameter Settings**

### SET STAKE

The parameter set here regulates the number of games per price of play. In this instance the limit can be set as follows

1 game/25cents up to and including 25 games/25cents.

### SET TICKET/PNTR

Entering this setting allows the selection of the ticket printer ON or OFF. The display toggles between ON and OFF using the left-hand and center buttons respectively.

### SET MERCY TICKET

The parameter set here regulates the number of tickets per price of play (25c).

Selecting 0 on the display sets the mercy ticket OFF.

Selecting between 1 and 10 on the display regulates the number of tickets per price of play (25c).

### SET PRIZE LEFT

The parameter set here regulates the number of points required by the player to obtain a prize from the left-hand vend unit.

This point selection can be regulated between 100 and 10,000 points.

### SET PRIZE RIGHT

The parameter set here regulates the number of points required by the player to obtain a prize from the right-hand vend unit.

This point selection can be regulated between 100 and 10,000 points.

### DISPLAY VIB

The display indicates the vibration readout.

On entering this procedure, VIB CTR is displayed. Jolting the machine will give a feel/indication of the vibration sensitivity and the required setting.

## **Regulated Parameter Settings**

### SET VIB LEVEL

The parameter set here regulates the vibration setting.

This sensitivity level can be set between 50 and 150.

### AUTO LOAD BED

This procedure is used to initially auto-load the coin bed. The bed will auto-fill via the escalator hopper until 100 coins have been sensed falling off the playfield.

## Regulated Test Sequences & Procedures

A test facility is provided to check the machines inputs and outputs.

The following tests are only applicable to machines with an alphanumeric fitted. During test, the front door must remain open, the machine must not be in credit or the counters will not operate.

To enter the test routines open the front door of the machine and press the green test switch once.

The following rules apply to all tests:

1. To step forward through tests press the left-hand button.
2. To step backwards through tests press the centre button.
3. To select any tests press the right hand button.
4. To exit from any test press the right hand button.

Each test is identified as follows:

TEST 1.1 COIN IN	TEST 7.1 COMMS	TEST 10.1 LAMPS
TEST 1.3 NOTES IN	TEST 8.1 AUDIO	TEST 10.3 CLEAR NVR
TEST 3.2 LAMPS	TEST 8.2 VOLUME	TEST 10.4 COIN DATA
TEST 6.1 METERS		

## Regulated Test Sequences & Procedures

### TEST 1.1 COIN IN

At test commencement, it is advisable to have the top door open.

On entering this test, the left-hand and the right hand buttons will flash.

In this state all coins are accepted and sent to the cash box or the appropriate hopper.

On placing a coin in the acceptor the alphanumeric will display one of the following messages (illustrated in bold text);

<u>Coin Entered</u>	<u>Displayed Alphanumeric Message</u>
25c	<b>???????</b>

Pressing the left-hand button once will cause a reject of all coinage on acceptor entry.

Pressing the left-hand button once again reverts the coin acceptance back to its initial state.

Pressing the center button will set Divert mode. Only coins that can be diverted from their respective hopper will display the **DIV** message.

<u>Coin Entered</u>	<u>Displayed Alphanumeric Message</u>
25c	<b>??????DIV</b>

Pressing the button 2<sup>nd</sup> from the left once again reverts the coin acceptance back to its initial state.

Pressing the right hand button exits the test and advances to  
TEST 1.3 NOTES IN

## Regulated Test Sequences & Procedures

### TEST 1.3 NOTES IN

On entering this test, the left hand and the right hand buttons will flash.

The alphanumeric will display **1.3 NOTES IN**

Inserting a note into the note acceptor the following steps apply;

#### \$1 Note Insert

- a) note accepted
- b) audio bleep confirming acceptance
- c) note returned
- d) Alphanumeric displays **1.3 1D ACC**

#### \$2 Note Insert

- a) note accepted
- b) audio bleep confirming acceptance
- c) note returned
- d) Alphanumeric displays **1.3 2D ACC**

#### \$5 Note Insert

- a) note accepted
- b) audio bleep confirming acceptance
- c) note returned
- d) Alphanumeric displays **1.3 5D ACC**

Pressing the left hand button will,

- i) inhibit note acceptance
- ii) extinguish the lamps above the note acceptor
- iii) display on the alphanumeric **1.3 NOTES IN INH**

Pressing the left hand button once more will revert back to note acceptance.

Pressing the right hand button exits the test and advances to TEST 3.2 LAMPS

## Regulated Test Sequences & Procedures

### TEST 3.2 LAMPS

On entering this test the alphanumeric displays **3.2 FLASH** and all lamps will continually flash.

Pressing the left-hand button stops all but one lamp flashing.

On each individual press the left-hand button toggles between a single and all lamps flashing.

The alphanumeric now displays (for example) **3.2 000 CANCEL**

where **000** = lamp number,

and **CANCEL** = the text illuminated by the lamp

The buttons 2<sup>nd</sup> and 3<sup>rd</sup> from the right on the panel are active;

- i) pressing the button 2<sup>nd</sup> from the right steps the display to the next lamp in sequence.
- ii) pressing the button 3<sup>rd</sup> from the right steps the display to the previous lamp in sequence

Pressing the right hand button exits the test and advances to TEST 6.1 METERS

### TEST 6.1 METERS

On entering this test only the left and right hand buttons flash.

The alphanumeric displays **6.1 METERS**.

Pressing the left-hand button initiates the SEC (Starpoint Electronic Counter) meter testing. The alphanumeric displays one of the following two messages;

**6.1 METER OK (implying the SEC meter test passes)**

**6.2 METER FAULT (implying the SEC meter test fails)**

Pressing the right hand button exits the test and advances to TEST 7.1 COMMS

## Regulated Test Sequences & Procedures

### TEST 7.1 COMMS

On entering this test the alphanumeric briefly displays **COMMS PORT 1** to indicate the port being tested.

If nothing is connected to this port, the display indicates **PORT FAIL**

If a Data Pack is connected to this port, the display indicates **DPAK PASS**

If pins 2 and 3 are shorted on the 25-way connector on the MPU, the display indicates **PORT PASS**

Pressing the right hand button exits the test and advances to TEST 8.1 AUDIO

### TEST 8.1 AUDIO

On entering this test a sound sample is audible. This sample is tested on each of the eight sound channels.

For each channel tested the alphanumeric will display the channel being tested. e.g. For a test of channel 5, the alphanumeric displays **8.1 SOUND CHAN 5**

Pressing the right hand button exits the test and advances to TEST 8.2 VOLUME

## Regulated Test Sequences & Procedures

### TEST 8.2 VOLUME

On entering this test the right-hand and second from the left-hand buttons flash. The left-hand button may also flash. This is dependent on the volume level already set on the machine (no volume and the left-hand button will not illuminate).

Control of the volume is as follows;

- i) Pressing the button second from the left increases the volume
- ii) Pressing the left-hand button decreases the volume

During this test the alphanumeric displays the percentage volume set. 100% can be indicated.

e.g. A volume set at 3 % will be displayed as **8.2 VOL MAIN 3PC**

Pressing the right hand button exits the test and advances to TEST 10.1 LAMPS

### TEST 10.1 LAMPS

On entering this test all lamps machine lamps begin to flicker.

(This test works in conjunction with Output Allocations in Section Two)

Pressing the button second from the left stops the lamps flashing and the alphanumeric displays **10.1 ST 0 DAT 0.**

Throughout the test, the display indicates the strobe and data information for the lamp illuminated.

The buttons on the panel have the following test functions;

- i) the button second from the left steps through the strobe information for each lamp.
2. the button fifth from the left illuminates all the lamps on a strobe line. This is used in conjunction with the button second from the left to step through the strobes.

## Regulated Test Sequences & Procedures

- iii) the button fourth from the left steps through the data information for each lamp. It also cancels the effects of pressing the button fifth from the left.
- iv) the button third from the left causes all lamps to flash. It also cancels the effects of pressing the button fifth from the left.

Pressing the right hand button exits the test and advances to TEST 10.4 COIN DATA

### TEST 10.4 COIN DATA

On entering this test the right-hand and second from the left-hand buttons flash.

The Alphanumeric will display **25c IN** **"A"**  
where **"A"** = the number of quarters in the machine.

Pressing the button second from the left will sequentially step through the coin data as follows;

- |    |               |            |    |              |            |
|----|---------------|------------|----|--------------|------------|
| 1. | <b>25c IN</b> | <b>"A"</b> | 3. | <b>2D IN</b> | <b>"A"</b> |
| 2. | <b>1D IN</b>  | <b>"A"</b> | 4. | <b>5D IN</b> | <b>"A"</b> |

Pressing the right hand button exits the test and advances to TEST 10.5 GAME DATA

To clear the coin data re-enter test 10.4. Turn the refill key to the ON position. '10.4 CLEAR DATA?' will be displayed, the buttons will illuminate and should be depressed in order, left to right.

'10.4 DATA CLEARED' will now be displayed.

The button lamps will now extinguish and the machine advances to TEST 1.1 COIN IN

Turn the refill key OFF.

## Regulated Test Sequences & Procedures

### DEMONSTRATION MODE

With the front door open press the Start button and 50 credits will be displayed on the LED or alphanumeric display.

On entering the Demonstration mode a number of options are available:-

- a) The game can be played normally.
- b) By holding down the cancel button and any hold button the reel relating to the hold button can be stepped down to any position. All the reels will then be held for the next game. The reels can also be stepped up by holding down the cancel and collect button simultaneously and then the relative hold button.



## DIL Switch Settings and Functions


The standard settings for our machines will be with all 16 switches OFF. However, this can be varied to suit local conditions, as follows:

1. Not used.
2. THIS DIL SWITCH MUST REMAIN IN THE OFF POSITION AT ALL TIMES
3. THIS DIL SWITCH MUST REMAIN IN THE OFF POSITION AT ALL TIMES
4. Not Used
5. Not Used
6. Not Used
7. Not Used
8. Not Used
9. Not Used
10. THIS DIL SWITCH MUST REMAIN IN THE OFF POSITION AT ALL TIMES
11. Sound Effect In Attract Mode  
With the DIL switch OFF, the sound effects are available.  
With the switch ON, the sound effects are NOT available.
12. Invert Swing Arm Action  
With the DIL switch OFF, the arm movement is available.  
With the switch ON, the arm movement stops.


## DIL Switch Settings and Functions

13. THIS DIL SWITCH MUST REMAIN IN THE OFF POSITION AT ALL TIMES
14. THIS DIL SWITCH MUST REMAIN IN THE OFF POSITION AT ALL TIMES
15. THIS DIL SWITCH MUST REMAIN IN THE OFF POSITION AT ALL TIMES
16. Menu Set Up  
With the switch in the OFF the MENU is unavailable.  
With the switch in the ON position the MENU can be entered.

# Machine BOM (Illustrated)



TICKET FRONT PANEL  
91.017.736



LH SIDE COVER  
91.017.738

RH SIDE COVER  
91.017.737



UPPER GLASS SCREENED  
92.933.539




SKILL CHUTE  
FRONT  
91.017.736




PLAYFIELD GLASS SCREENED  
92.933.541

# Machine BOM (Illustrated)



## Machine BOM (Illustrated)



99095067 – OUTER CASH BOX DOOR ASSEMBLY

Note Readers (not shown)

90520138 - PLATE CARD READER MTG (INTERCARD)

90520139 - PLATE CARD READER MTG (RECO)


90520140 - PLATE CARD READER MTG (KDE)

90520141 - CHASSIS CARD READER MTG (KDE)

90520142 - PLATE CARD READER MTG (DKS)

90520143 - PLATE USA CARD READER BLANKING

48811100 - LOCKS (SET OF 4) BATTON RADIAL LOCKS




40272 - CAM

94849102 – LATCH SPACER  
BLOCK (WOODEN)

90306231 - LATCH PLATE

90522807 - MPU BASE ECLIPSE 2001

## Machine BOM (Illustrated)




90306196 - GRILL

96912100 - MAINS DISTRIBUTION ASSY

90307068 - VENT GRILL PLATE FAN

90307484 - FAN MOUNTING PLATE& STUDS

51730009 - TERMINATED FAN 80X80X38MM MAINS 230V



49117010 - GAS STRUT 310 NEWTONS 255MM STROKE

49117000 - GAS STRUT BALL END


90857992 - STRUT MOUNTING BKT STD ECLIPSE

94895065 - SPACER CHUTE BRACKET

90850048 - BRACKET HOPPER CHUTES FIXING

91802102 - COIN CHUTE CASH BOX

## Machine BOM (Illustrated)




51520287 - HOPPER 'U' MEDIUM BOWL

90520146 - CHASSIS HOPPER USA SINGLE PUSHER

90873843 - P/O PRINTER GUIDE BRACKET

90864314 - DOOR SECURITY BRACKET


96876316 - HOPPER HARNESS




57520010 - PUSH SW DP  
CHERRY UE79-68A

90850104 - BRACKET  
ACCESS DOOR SWITCH

## Machine BOM (Illustrated)




- 90623374 - WEIGHT WIRE
- 90623375 - CONTACT WIRE
- 90850016 - BRACKET TILT BOARD MOUNTING
- 90442238 - TILT WEIGHT
- 90442240 - STEEL BALL- 3/8" DIA
- 94895081 - TILT MOUNTING BLOCK
- 36119001 - VEND INTERFACE PCBA



- 91802100 - LOSE CHUTE RH ANGLED (K159)
- 91802098 - COIN CHUTE LH LOSE
- 90850065 - BRACKET LH LOSE CHUTE

## Machine BOM (Illustrated)



57520040 – DOOR SWITCH (PUSH/PULL)

90851150 - DOUBLE POLE SWITCH BRKT

53713347 - TRANSFORMER 500va

96941333 - POWER SUPPLY (STADIUM)

96941341 - POWER SUPPLY ESCALATOR HOPPER

51520306 - 10P ESCALATOR HPR ASHAI SEIKO

90850111 - ESCALATOR HPR MOUNTING BRACKET ASSY

## Machine BOM

Part Number	Description
36801004	PCBA AUXILLARY SCP4 8 MEG SOUND PROM
36821001	PCBA DOT MATRIX ALPHA FUTABA 12.5MM
41709	45 DEG ANGLE SPADE TERMINAL AMP
48011101	PLASTIC RIVET 4MM DIA MOSS 39158 or 32517
48011106	4MM PLASTIC RIVET BLK RICHCO SR4080
48011106	4MM PLASTIC RIVET BLK RICHCO SR4080
48011107	4MM PLASTIC RIVET BLK RICHCO SR4050
49412001	BLIND HOLE SUPPORT RICHCO
49412212	SPACER RICHCO SS10-2 6.4MM LONG
49420010	LINEAR GUIDECZ0201-3094
49433001	LOCATION PAD
51802086	OPTIC PCBA 15RM STD1155
51802131	90MM OPTIC A2404
51802134	MOTOR 200STEP & LOOM GAMESMAN G4-471
51900003	MOTOR 240V 24RPM PANASONIC G SERIES
52910200	SPEAKER 4 OHM 15WATTPF-365-504
53100002	TICKET DISPENSER DELTRONIC DL455
54151102	MATE & LOCK SOCKET PIN
54750214	2W PLUG HOUSING MATE & LOCK 350777-1
54750315	03W MINI MATE-N-LOK FEMALE RS115-1777
55806304	INSULATING BOOT TYPE C MAINS FILTER
56129060	LAMP DICHROIC 12V/35W 50MM DIAMETER
56609036	5MM WEDGE L/HLDR & CLEAR BULB AMP IDC
57081161	GPB310/5KKH TRANS YELLOW ASSY
57081181	GPB340/5 KKH TRANS YELLOW ASSY
57520010	PUSH SW DP CHERRY UE79-68A
57611004	MOMENTARY ROCKER SWITCH
73799002	INLINE DIODE HOLDER (IDC) BLK
73799003	INLINE LINK HOLDER (IDC) WHITE
75781170	IC SGS 27C4001-12F1 EPRO M STM

## Machine BOM

Part Number	Description
75781181	IC 8 MEG OPT EPROM M27C801-100B1 DIL
77020080	PANEL MOUNTED RED LED 12V FEPL 5W12
78500006	MAINS FILTER SCHAFFNER FN 9222-6-06
90307360	SPACER PLATE LOCK LATCH BRACKET
90307506	WADDING RETAINING PLATE
90442242	SPACER
90467001	HINGE REAR PANEL DOOR
90467297	HINGE CASTING ECLIPSE
90520073	PLATE PUSHER TRACK/MOTOR
90520074	PLATE MOTOR
90520075	PLATE PLAYFIELD
90520076	PLATE PUSHER
90520087	COVER R/H SIDE BLOCK (11427)
90520088	COVER L/H SIDE BLOCK (11428)
90520089	PLATE C/BOX DOOR LAMP MTG U.S. (11435)
90520136	PLATE ACCESS DOOR COVER
90520137	PLATE NOTE VALIDATOR BEZEL (MARS)
90520147	RISER ASSY USA SINGLE PUSHER
90623003	SPACER MOTOR
90623004	ARM DRIVE
90623005	BLOCK DRIVE (NYLON)
90623006	BLOCK PUSHER (NYLON)
90623007	BLOCK CENTRE (NYLON)
90623008	BOSS DRIVE
90623009	COUPLING DRIVE
90623010	RAIL GUIDE
90623011	BLOCK SIDE (NYLON)
90623012	BEARING FLANGE HOUSED (RS109-927)
90623013	SPACER M3 x 30MM BRASS (RS222-446)
90850044	BRACKET DOOR CLOAKING STRIP

## Machine BOM

Part Number	Description
90850045	BRACKER ESCALATOR TRACK SUPPORT
90850050	BRACKET RH CENTRE SUPPORT RAIL
90850051	BRACKET LH CENTRE SUPPORT RAIL
90850052	BRACKET PUSHER FRONT
90850053	BRACKET CENTRE PERSPEX SUPPORT
90850054	BRACKET RH PLAYFIELD SIDE
90850055	BRACKET LH PLAYFIELD SIDE
90850056	BRACKET STEPPER MOTOR
90850057	BRACKET ESCALATOR SUPPORT
90850058	BRACKET PLAYFIELD SUPPORT
90850062	BRACKET OPTIC SENSOR MOUNTING (11437)
90850063	BRACKET LAMP & V/F SECURING
90850067	BRACKET RH LOSE CHUTE ASSY
90850080	BRACKET LOSE HOLE ADJUSTER
90850081	BRACKET CENTRE PERSPEX RETAINING
90850088	BRACKET WIN CHUTE
90850091	BRACKET HALOGEN LAMP
90850105	BRACKET N/VAL CLAMP (MEI SERIES 2000)
90850106	BRACKET ESCALATOR HOPPER TRACK SUPPORT
90854300	DOOR SWITCH COVER BRACKET
90864315	CLOAKING BRACKET DISPLAY DOOR
90866584	LATCH COVER BRACKET & STUDS
90866585	PSU LOCATION BRACKET ECLIPSE
90866632	TILT BRACKET
90867583	LATCH BRACKET
90873610	MOMENTARY SWITCH BRACKET
90873668	LOCATION BRKT PAYSLIDE PSU
90873774	VAC FORM SECURING BRACKET
90873777	LOCK LATCH BRACKET & STUD
90873777	LOCK LATCH BRACKET & STUD

## Machine BOM

<b>Part Number</b>	<b>Description</b>
90873778	LOCK ACTUATOR BRKT
90873842	P/O PRINTER FASCIA BRACKET
91010034	FRONT PERSPEX
91010035	SIDE STRIP
91010036	COIN SKIMMER
91017746	DOOR DECAL JUMPING BEAN
91017846	25C PLAY DECAL QUARTERBACK PUSHER
91017847	50C PLAY DECAL QUARTERBACK PUSHER
91017848	\$1 PLAY DECAL QUARTERBACK PUSHER
91017849	POINTS FOR PRIZES DECAL QUARTERBACK PUSHER
91017850	FIGURE DECAL QUARTERBACK PUSHER
91017936	TICKET FRONT PANEL USA QUARTERBACK
9101793	5c A SHOT DECAL USA QUARTERBACK
91451467	SHROUD COVER - TRICOLOUR LED
91451484	MPU INSULATING PLATE
91682502	PUSHER PAD (2720)
91771095	CASHBOX - 180MM HIGH
91771234	MAINS DISTRIBUTION COVER
91771361	SKILL CHUTE FORMING
91771363	WIN CHUTE FORMING
91772524	DISP MASK FORMING USA QUARTERBACK
91802095	TOP COIN CHUTE
91802097	COIN CHUTE RH LOSE
92207123	G'MANUAL 93738211 USA QUARTERBACK
92477370	LEGEND PLATES,3/ST, QUATERBACK
92751546	LABEL - EARTHING POINT 2000/RL
92751454	LABEL - PATENTS
92751511	APPLIANCE TEST LOG
92751840	LABEL – POWER SUPPLY
92752030	110V WARNING LABEL

## Machine BOM

Part Number	Description
92752040	230V WARNING LABEL
92752128	SCORPION 4 LAYOUT
92752129	JUMPING BEAN COPYRIGHT LABEL
92920692	MIRROR
94895057	TILT BOARD
94895064	HOPPER SHELF
94895066	PLAYFIELD PANEL
94895067	COIN CHUTE SPACER
96832547	LEAD ASSY MAINS DIST BOX SUPPLY
96832577	MAINS LEAD 925MM LONG R/A SOCKET
96875553	ALPHANUMERIC HARNESS ASSY
96875919	MPU/PSU (HI MPU) HARNESS
96876308	TICKET DISPENSER ILLUMINATION HARNESS
96876310	MAIN HARNESS
96876311	MOTOR/OPTICS HARNESS
96876312	ESCALATOR SENSOR HARNESS
96876313	HOPPER SENSOR HARNESS
96876314	COIN MECH EXTENSION HARNESS
96876315	FAN ASSEMBLY HARNESS
96876317	HALOGEN LAMP SUPPLY HARNESS
96876318	PAD MOTOR ASSY HARNESS
96876319	HALOGEN SPRING CLIP HARNESS
96876320	VIBRATION SENSOR HARNESS
96876321	EARTH HARNESS
96876322	115V MAINS IN LEAD
96876323	115V DIST TO TX LEAD
96876324	240V STEP UP TX TO DIST LEAD
96876325	240V FAN & MOTOR LEAD
96876326	240V DIST TO STADIUM PSU LEAD
96876327	240V DIST TO ESCALATOR PSU LEAD

## Machine BOM


<b>Part Number</b>	<b>Description</b>
96876328	240V DIST TO HALOGEN TX LEAD
96876329	BUTTON PANEL/ROCKER SWITCH HARNESS
96876330	BILL ACCEPTOR HARNESS
96876331	MPU INTERFACE HARNESS
97042606	DOOR FRAME ASSY TRANS RED
97854317	MAINS PLATE & STUD ASSY ECLIPSE
97854322	LATCH & SWTS BKT & CLINCH NUT ASSY

Data Retrieval RS232

plug L Arm & Token Sensors

plug G Vend Outputs

plug F Arm Drives



plug J Hopper Data

plug B Hopper Drives

plug D Alpha Display

plug R 12v Supply

plug H Coin Acceptor

plug E Meter Outputs

plug K Meter Outputs

plug F Serial i/p

plug S Audio

plug A Power

plug Q Lamps

plug P Lamps

plug M Switch Inputs

plug N Not Used

plug O Not Used

DIL Switches